





From 96 on overload



CONTROL WIRING OF STAR DELT

PHASE

THERMAL OVER LOAD RELAY

STOP

START


MAIN
AUX
CONTACT
KM3


TIMER
AUX
CONTACT
KT

DELTA
CONTACT
KM2



TIMER
AUX
CONTACT
KT

STAR
CONTACT





Control Circuit Diagram of Automatic Star Delta (Y-Δ) starter with Timer for 3-Phase Motor.



S0 = 'OFF' push button
 S1 = 'ON' push button
 K1 = Line contactor
 K2 = Stat contactor
 K3 = Delta contactor
 K4 = Star delta timer
 F2 = Overload relay
 F1 = Backup fuse

